

Non-destructive Measurements of Total Soluble Solids in Chocolate Persimmon (*Diospyros kaki*)

Sugar (Total Soluble Solids (TSS) or °Brix) content is regularly measured in persimmons throughout development and storage. Using traditional methodology, TSS measurements are destructive and time consuming. To determine effectiveness and viability of the F-750 Produce Quality Meter for non-destructive measurements of TSS in persimmon, a modeling study was conducted on 20 chocolate persimmons. Destructive reference values were correlated with the non-destructive spectral data collected with the F-750 using the F-750 Model Builder Software, and results show that the F-750 Produce Quality Meter precisely and non-destructively measures TSS in persimmon, with a calculated root mean square error of cross validation of 0.79 TSS.

Materials and Methods:

In September 2015, 20 chocolate persimmons were used to create a new model for the F-750 Produce



Figure 1. Fruit presentation for measuring persimmon with the F-750.

Quality Meter. Using the screws on the lens housing as alignment markers, persimmons were consistently presented and scanned on the F-750 Produce Quality Meter at room temperature (20°C). Next, the same persimmon regions scanned with the F-750 were destructively measured for Total Soluble Solids (TSS) using the method described in Felix Instruments Mango Standard Operating Procedure (SOP). The spectral range of 729-969 nm was used by the F-750 Model Builder Software to detect correlations between the F-750 spectral signal and corresponding TSS values. The resulting regression data was analyzed for linearity, root mean square error, and leave-one-out cross validation error to determine the applicability and accuracy of the created model.

Results and Discussion:

Results show that the F-750 Produce Quality Meter precisely, simultaneously, and non-destructively measures the TSS of persimmon. A strong correlation between spectral data and collected reference values is illustrated by a model prediction R^2 of 0.92 for TSS. Figure 2 displays this correlation and demonstrates the consistency of measurement.

A calculated Root Mean Square Error of Cross Validation (RMSECV) of 0.79 TSS further illustrates the accuracy of the created model. This RMSECV value is an estimation or simulation of error for a given

measurement when the model is loaded onto the F-750 and used to predict TSS. The RMSECV is equivalent to the expected uncertainty within 68% of all predictions.

Conclusions:

The F-750 Produce Quality Meter accurately predicted Total Soluble Solids (TSS) in persimmon. Other tests and research findings have demonstrated the ability to measure other important internal fruit metrics with NIR technology. Similar results are expected for the F-750 Produce Quality Meter with other persimmon varieties and traits.

Further Reading and Supporting Science:

Jannok, P., Kamitanib, Y., & Kawanob, S. (2014). Development of a common calibration model for determining the Brix value of intact apple, pear and persimmon fruits by near infrared spectroscopy. *Journal of Near Infrared Spectroscopy*, 22(5): 367-373.

Liu, R., Qi, S., & Han, D. (2015). Measurement of soluble solids content of three fruit species using universal near infrared spectroscopy models. *Journal of Near Infrared Spectroscopy*, 23(5): 301-309.

Zanamwe, Pesanai. (2014). The role of harvest time and maturity, orchard and simulated wind on postharvest quality of 'Triumph' persimmon fruit and the potential of NIR as non-destructive sorting tool. *Thesis (MScAgric)*, Stellenbosch University.

For more information about commodities tested with the F-750, visit www.felixinstruments.com.




Figure 1. F-750 prediction value against reference method value of Total Soluble Solids in persimmon.